



4.6L 2V Mustang PowerSpacer

P/N 17-83

Congratulations on your purchase of a Holley 4.6L 2V Mustang PowerSpacer! The Holley PowerSpacer is designed to sandwich between the throttle body adapter and the plastic intake manifold. If you have any questions, please contact **Holley Technical Service at 270-781-9741**.

1. Either draw a sketch or mark the locations of the cables, hoses, and electrical connections by using a piece of masking tape to ensure the proper reinstallation of these items.
2. Disconnect all required cables, hoses, and electrical connections necessary to facilitate the removal of the throttle body and throttle body adapter.
3. Remove the five factory bolts that secure the throttle body adapter to the intake manifold with an 8mm socket.
4. Place the aluminum PowerSpacer on top of the intake manifold. Place the supplied gasket on top of the PowerSpacer.
5. Reinstall the throttle body adapter, using four of the five supplied bolts and a 10mm socket, torquing to 89 in./lbs.
6. Slip the supplied cylindrical spacer between the "leg" of the throttle body adapter and the intake manifold, and secure with the remaining bolt, using a 10mm socket (torquing to 89 in./lbs.).
7. Reconnect all required cables, hoses, and electrical connections in their original locations.
8. Reinstall the air inlet tube on the throttle body and tighten the clamp.
9. Test drive the vehicle, and enjoy!

199R10303

Revision Date: 10-17-12



4.6L 2V Mustang PowerSpacer

P/N 17-83

Congratulations on your purchase of a Holley 4.6L 2V Mustang PowerSpacer! The Holley PowerSpacer is designed to sandwich between the throttle body adapter and the plastic intake manifold. If you have any questions, please contact **Holley Technical Service at 270-781-9741**.

1. Either draw a sketch or mark the locations of the cables, hoses, and electrical connections by using a piece of masking tape to ensure the proper reinstallation of these items.
2. Disconnect all required cables, hoses, and electrical connections necessary to facilitate the removal of the throttle body and throttle body adapter.
3. Remove the five factory bolts that secure the throttle body adapter to the intake manifold with an 8mm socket.
4. Place the aluminum PowerSpacer on top of the intake manifold. Place the supplied gasket on top of the PowerSpacer.
5. Reinstall the throttle body adapter, using four of the five supplied bolts and a 10mm socket, torquing to 89 in./lbs.
6. Slip the supplied cylindrical spacer between the "leg" of the throttle body adapter and the intake manifold, and secure with the remaining bolt, using a 10mm socket (torquing to 89 in./lbs.).
7. Reconnect all required cables, hoses, and electrical connections in their original locations.
8. Reinstall the air inlet tube on the throttle body and tighten the clamp.
9. Test drive the vehicle, and enjoy!

199R10303

Revision Date: 10-17-12