



1978-88 GM A/G-BODY REAR EXIT DUAL TAILPIPE KIT
70401330-RHKR (2.5") & 70401331-RHKR (3")
Installation Instructions



Thank you for choosing to use HOOKER™ exhaust components as part of your A/G-body performance project. These tailpipes were designed as part of the most comprehensively engineered collection of LS swap mounting components, headers and exhaust systems for 1978-88 A/G-body vehicles, but can be also be installed with the Hooker A/G body exhaust system on a stock engine equipped A/G body through custom adaptation of the exhaust system inlet pipes.

PRE-INSTALLATION CONSIDERATIONS:

Check that the hardware package includes the following:

Qty.	Description	Qty.	Description	Qty.	Description
2	Hanger Brackets	4	5/16" x 1" Flanged Head Bolts	2	1/2" x 1-3/4" Bolts
2	"Z" Brackets	4	5/16" Flanged Head Nuts	2	1/2" Lock Nuts
2	M10 Bolts	2	Rubber Isolators	2	1/2" Flat Washers

If you are missing any hardware, please contact Technical Service at 1-866-464-6553 or 270-781-9741.

NOTE: These tailpipes were design to be compatible with any rear tire size that is installable within the constraints of the stock frame and body fitment envelope. Narrowing the rear frame to permit the installation of a wider tire may cause interference between the rear tires and these tailpipes.

An automotive lift or a jack and jack stands will be required to safely raise and support the vehicle. **CAUTION! WORK ONLY ON A LEVEL SURFACE. USE JACKS /JACK STANDS OF SUFFICIENT CAPACITY TO LIFT AND SUPPORT YOUR VEHICLE. NEVER WORK UNDER A VEHICLE SUPPORTED BY A FLOOR OR BUMPER JACK.**

INSTALLATION:

1. Remove the two bolts located on the bottom surface of the frame rails that anchor the rear bumper dampers to the frame. Install the supplied "Z" brackets to the frame on both sides of the vehicle using the supplied M10 bolts. Offset the brackets towards the rear of the car as shown in **Figure 1 (driver's side)** and **Figure 2 (passenger's side)**.
2. Install the supplied rubber isolators into the channels of the supplied hanger brackets and secure them in place with the supplied 1/2" bolts, washers, and nuts. Place the washer against the exposed face of the rubber isolator, not against the metal bracket.
3. Position two band clamps over the inlets of the tailpipes and install both assemblies onto the over-axle tubes of your Hooker exhaust system. These two clamps were supplied with the Hooker exhaust system for attachment of the tips. Do not fully tighten the clamps at this time.
4. Place the hanger bracket/rubber isolator assemblies over the hanger rods located on the tips and attach the hanger brackets to the faces of the "Z" brackets that are facing towards the center of the vehicle as shown in **Figure 3 (driver's side)** and **Figure 4 (passenger's side)**. Use the included 5/16" hardware for this purpose.
5. Align the tips and over-axes for best fitment and fully tighten the band clamps at the tailpipe inlets.



Figure 1



Figure 2



Figure 3



Figure 4

LIMITATION OF LIABILITY – DISCLAIMER:

The regulation of emissions production, noise levels, and safety standards is undertaken by the federal government, each of the fifty state legislatures, and by many local municipalities, towns, and counties.

HOOKER™ makes no warranties of merchantability, of fitness for particular purpose, or that its products are approved for general use, or that its products are approved for general use, or that its products comply with laws, regulations, or ordinances in the state where they may be sold to the ultimate purchaser, the consumer.

Unless expressly stated to the contrary in the catalog, instruction sheet; or price list, the entire risk as to the conformity of any company product in any such state and as to repair should the product prove to be defective or non-conforming, is on the retail purchaser, the buyer, the ultimate consumer, of such product and it is not upon the seller, distributor, or manufacturer.

In this connection, the retail purchaser, the buyer, the ultimate consumer assumes the burden of the entire cost of any and all necessary service, alterations, or repair.

THE FOREGOING STATEMENT LIMITS THE LIABILITY OF THE MANUFACTURER.

California vehicle code, sections 27156 and 38391, prohibits the advertising, offering for sale, or installation of any device, which modifies a vehicle's emission control system, unless exempted, unless otherwise noted. HOOKER™ Headers that have not received an Executive Order (E.O.) exemption from these code sections are not legal for sale or use in California on vehicles originally equipped with catalytic converters, except for racing vehicles, which may never be driven upon a highway. Check with your local authorities to determine if these headers are legal for use in your particular area.

Technical Service: 1-866-464-6553

Phone: 1-270-781-9741

For online help, please refer to the Tech Service section of our website: www.holley.com

© 2016 Hooker Headers, Inc. All rights reserved.

199R11018

Date: 3-9-16