



MUSCLE SERIES SBC VALVE COVER 241-134, 241-135, 241-136, & 241-137

INSTALLATION INSTRUCTIONS

To preserve the warranty, these instructions must be read and followed thoroughly BEFORE and DURING installation.

CAUTION! If your engine has non-standard valve train components, such as a high-lift camshaft, roller-tip rocker arm, higher lift ratio rocker arms, stud girdles, etc., there may be insufficient clearance when using the Holley Vintage Series aluminum valve cover. You must check all internal clearances according to steps 10-13 below.

WARNING! INSUFFICIENT CLEARANCE TO MOVING VALVE TRAIN COMPONENTS COULD LEAD TO PART BREAKAGE AND RESULT IN SERIOUS ENGINE DAMAGE.

COMPATIBLE ENGINE MODELS:

PART #	FINISH	MAKE	ENGINE	YEAR
241-134	Natural	Chevrolet Small Block V8	262,283,302,305, 307, 327,350,& 400	1958 and up with perimeter bolt pattern
241-135	Black			
241-136	Orange			
241-137	Polished			

RECOMMENDED TOOLS FOR INSTALLATION:

3/8" Ratchet Handle	Scraper Blade
1/2" or Similarly Sized Socket	Adhesive Gasket Sealant
6" Socket Extension	Torque Wrench

LIST OF INCLUDED PARTS:

QTY. IN BOX	PART DESCRIPTION
1	Valve Cover, Muscle Series, Punched
1	Valve Cover, Muscle Series, UnPunched
2	Square Top PCV Grommet, Rubber
1	Vintage Style Oil Fill Cap, Twist On
1	Holley Emblem, Round
1	Warranty Statement – 90 Day
1	Installation Instructions

INSTALLATION INSTRUCTIONS:

CAUTION! Never work on a hot engine. Open the hood and allow all components to cool before installing.

1. Remove any oil fill caps, PCV components, or wires that are attached to the existing valve cover.
2. Remove the existing valve cover hardware and covers, then carefully clean any gasket material that adheres to the head surface. Do not allow any gasket debris to enter the engine.
3. Install the rubber PCV valve grommet into the pre-punched, internally baffled hole in your Holley Muscle Series valve cover.
4. Install the included Holley emblem into the recessed area on top of your unpunched Holley Muscle Series valve cover by removing the protective film from the adhesive backing and aligning the emblem in the designated area. Press firmly to ensure proper adhesion.
5. Install the new valve cover gaskets in the Holley Muscle Series valve covers using an adhesive type gasket sealant (if applicable).
6. If you are using 100% stock valve train components, then install the valve covers. **If any parts of the valve gear are aftermarket, see steps 10-13 to ensure proper clearances.**
7. Torque the valve cover bolts to 5-6 ft./lbs., making sure the gaskets do not slip out of position. Proper torquing will help to ensure that your covers do not leak oil.
8. Re-install any applicable items removed in Step 1.
9. Start the engine and carefully check for any signs of oil leakage.

-
10. Place small pieces of modeling clay on any protruding areas of the valve train (both moving and stationary). Include the following: both tips of the rocker arms, the pushrods (closest to the valve cover flange surface), on the rocker arm studs, or on the rocker shaft attachments. In general, check all the points that you are not sure about.
 11. Install the valve cover, using the correct gasket and tighten the valve cover hardware to 5-6 ft./lbs. of torque. Turn the engine over by hand or with a SHORT lever, at least two full revolutions of the flywheel. Removing the spark plugs is advised.

CAUTION! Be alert for any signs of unusual binding as the engine is turned. If binding occurs; stop turning immediately, remove the valve cover, and check the clay pieces. **DO NOT FORCE THE ENGINE TO TURN.**

12. After two complete revolutions, remove the valve cover and check the clay thickness with a depth micrometer, or suitable instrument. Clay should compress to no thinner than .080" at any point for moving parts, and no thinner than .040" for stationary parts.

NOTE: If the clearance is not acceptable according to Step 12, Holley recommends that you install a spacer to increase clearance to the valve cover.

13. If the valve train clearance is acceptable, carefully remove all traces of the modeling clay from the engine. Return to step 7 and complete the installation.

If you have any questions or concerns, please do not hesitate to contact us using the information below:

Holley Technical Support Toll Free: 1-866-464-6553

Phone: 1-270-781-9741

www.holley.com

199R11019

Revision Date: 8-11-16