



**OIL IN KOOL CAN  
#1350**

**INSTALLATION OF COIL IN KOOL CAN**

1. Remove coil from Kool Can.
2. Install rubber grommets in holes on side of Kool Can.
3. Before putting coil back into Kool Can, coat coil and rubber grommets with silicone or soap and water so coil will slide through grommet.
4. Slip coil back into can by starting coil into first grommet and then slip into second grommet.

**NOTE:** Be careful not to force coil into or out of the can. A small amount of pressure will do the job.

**199R11562  
Date: 4-23-18**



**OIL IN KOOL CAN  
#1350**

**INSTALLATION OF COIL IN KOOL CAN**

1. Remove coil from Kool Can.
2. Install rubber grommets in holes on side of Kool Can.
3. Before putting coil back into Kool Can, coat coil and rubber grommets with silicone or soap and water so coil will slide through grommet.
4. Slip coil back into can by starting coil into first grommet and then slip into second grommet.

**NOTE:** Be careful not to force coil into or out of the can. A small amount of pressure will do the job.

**199R11562  
Date: 4-23-18**



**OIL IN KOOL CAN  
#1350**

**INSTALLATION OF COIL IN KOOL CAN**

1. Remove coil from Kool Can.
2. Install rubber grommets in holes on side of Kool Can.
3. Before putting coil back into Kool Can, coat coil and rubber grommets with silicone or soap and water so coil will slide through grommet.
4. Slip coil back into can by starting coil into first grommet and then slip into second grommet.

**NOTE:** Be careful not to force coil into or out of the can. A small amount of pressure will do the job.

**199R11562  
Date: 4-23-18**



**OIL IN KOOL CAN  
#1350**

**INSTALLATION OF COIL IN KOOL CAN**

1. Remove coil from Kool Can.
2. Install rubber grommets in holes on side of Kool Can.
3. Before putting coil back into Kool Can, coat coil and rubber grommets with silicone or soap and water so coil will slide through grommet.
4. Slip coil back into can by starting coil into first grommet and then slip into second grommet.

**NOTE:** Be careful not to force coil into or out of the can. A small amount of pressure will do the job.

**199R11562  
Date: 4-23-18**



**OIL IN KOOL CAN  
#1350**

**INSTALLATION OF COIL IN KOOL CAN**

1. Remove coil from Kool Can.
2. Install rubber grommets in holes on side of Kool Can.
3. Before putting coil back into Kool Can, coat coil and rubber grommets with silicone or soap and water so coil will slide through grommet.
4. Slip coil back into can by starting coil into first grommet and then slip into second grommet.

**NOTE:** Be careful not to force coil into or out of the can. A small amount of pressure will do the job.

**199R11562  
Date: 4-23-18**



**OIL IN KOOL CAN  
#1350**

**INSTALLATION OF COIL IN KOOL CAN**

1. Remove coil from Kool Can.
2. Install rubber grommets in holes on side of Kool Can.
3. Before putting coil back into Kool Can, coat coil and rubber grommets with silicone or soap and water so coil will slide through grommet.
4. Slip coil back into can by starting coil into first grommet and then slip into second grommet.

**NOTE:** Be careful not to force coil into or out of the can. A small amount of pressure will do the job.

**199R11562  
Date: 4-23-18**