



FORD KICK-DOWN SPRING & PERCH KIT KIT P/N 1954

All new manufactured Street Demon™ Carburetors come with a Ford kick-down linkage. If running a Ford automatic and the kickdown linkage is needed, a spring and perch kit (P/N 1954) is required.

NOTE: Street Demon™ Carburetors will not work with a Ford AOD transmission.

1. Press the screw retainer into position (Fig. 1).
2. Remove shipping screw (Fig. 2).
3. Install adjustment screw and locknut (Fig. 3). Consult the Ford Service Manual for proper setting.
4. Install the mounting bracket and return spring (Fig. 4).



Figure 1



Figure 2



Figure 3



Figure 4

WARNING: Install the transmission kickdown adjustment screw retainer, adjustment screw, and locknut, as correctly indicated. Failure to attend to this detail may result in a sticking wide-open throttle or dangerous uncontrolled engine speed.

LIT717

Date: 5-7-12