



Fuel Line Kit—P/N 7093 Installation Instructions for Holley 4150 Series Carburetors

NOTE: Oil all threaded parts before assembling.

1. Install the 4 fittings provided for the carburetors fuel inlets.
2. Replace the two 3/8" Allen bolts in the center of the carburetor adapter plate with the two 3/8"-16 "low head" bolts supplied.
3. Assemble the distribution block with the fittings provided.

CAUTION! Do not over tighten the fittings with o-rings or damage might incur.

NOTE: Leave all the tube nuts on the fuel lines fingertight, until assembly is complete.

4. Install the shortest line on the rear carburetor right-hand (passenger) side with the short end attaching to the carburetor.
5. With the #8 fitting oil distribution block facing away from the carburetors, attach the other end of the short line onto the lower fitting of the distribution block left-hand (driver) side.
6. Install the next shortest line on the front carburetor right-hand (passenger) side with the 10° bent end attaching to the carburetor. Attach the other end of the line to the lower fitting on the right-hand (passenger) side of the distribution block.
7. Install the line with the bends facing away from each other on to the front carburetor, left-hand (driver) side, attaching the shortest end onto the carburetor.
8. Install the remaining line with the shortest end attaching to the rear carburetor.

W544

Revision Date: 5-8-12



Fuel Line Kit—P/N 7093 Installation Instructions for Holley 4150 Series Carburetors

NOTE: Oil all threaded parts before assembling.

1. Install the 4 fittings provided for the carburetors fuel inlets.
2. Replace the two 3/8" Allen bolts in the center of the carburetor adapter plate with the two 3/8"-16 "low head" bolts supplied.
3. Assemble the distribution block with the fittings provided.

CAUTION! Do not over tighten the fittings with o-rings or damage might incur.

NOTE: Leave all the tube nuts on the fuel lines fingertight, until assembly is complete.

4. Install the shortest line on the rear carburetor right-hand (passenger) side with the short end attaching to the carburetor.
5. With the #8 fitting oil distribution block facing away from the carburetors, attach the other end of the short line onto the lower fitting of the distribution block left-hand (driver) side.
6. Install the next shortest line on the front carburetor right-hand (passenger) side with the 10° bent end attaching to the carburetor. Attach the other end of the line to the lower fitting on the right-hand (passenger) side of the distribution block.
7. Install the line with the bends facing away from each other on to the front carburetor, left-hand (driver) side, attaching the shortest end onto the carburetor.
8. Install the remaining line with the shortest end attaching to the rear carburetor.

W544

Revision Date: 5-8-12