



**Installation Instructions**  
**15919, 15920FM, 15921**  
**UNIVERSAL H-PIPE**  
 2¼", 2½" & 3"

At Flowmaster™ we take pride in being *The Exhaust Technology Company™*. Our mission is to provide the most technologically advanced, highest quality exhaust products in the world.

**THE FOLLOWING ARE SOME HELPFUL TIPS WHEN INSTALLING YOUR SYSTEM:**

For installing into an existing system, locate a section of straight tubing that allows you to cut 7.5" out of both exhaust pipes. This will allow you to slide the welded H-pipe onto one side of the cut out section then slide it back to fill the gap.

Before welding or clamping your T-connector in place; measure and possibly trim either the straight or bent crossover for installation into the side assembly slip-fits.

When installing the H-pipe, be sure the entire assembly has enough clearance to prevent any damage to the vehicle, a minimum of ¾" is recommended.

15919			15920			15921		
PART #	DESCRIPTION	QTY.	PART #	DESCRIPTION	QTY.	PART #	DESCRIPTION	QTY.
268TB	T-Connector	2	267TB	T-Connector	2	269TB	T-Connector	2
TB299	Crossover-Straight	1	TB299	Crossover-Straight	1	TB306	Crossover-Straight	1
TB16090	Crossover-Bent	1	TB16090	Crossover-Bent	1	TB16162	Crossover-Bent	1
PK919	Hardware Pack includes:	1	PK920	Hardware Pack includes:	1	PK921	Hardware Pack includes:	1
MC200S	2" Clamps	2	MC200S	2" Clamps	2	MC250S	2½" Clamps	2
MC214S	2¼" Clamps	4	MC250S	2½" Clamps	4	MC300G	3" Clamps	4

