

1996-2004 Ford Mustang GT X-Pipe 70803305-RHKR (304SS) & 70803306-RHKR (409SS) Installation Instructions



Thank you for making HOOKER HEADERS your choice in a high-performance exhaust system. Extensive dyno/track testing has enabled HOOKER to offer the most advanced design in exhaust systems. The installation, while not complex, will take a certain amount of time. However, the additional horsepower and improved performance will more than justify your efforts. Proper installation and maintenance will ensure long life and maximum performance from your HOOKER BLACKHEART exhaust system.

BEFORE STARTING:

Your vehicle must be raised a minimum of 18 inches. A floor hoist is ideal. If no hoist is available, we strongly urge the use of axle stands as a safety measure. Please read and understand these instructions and disclaimer in their entirety before attempting installation.

CAUTION! WORK ONLY ON A LEVEL SURFACE. USE JACKS /JACK STANDS OF SUFFICIENT CAPACITY TO LIFT AND SUPPORT YOUR VEHICLE. NEVER WORK UNDER A VEHICLE SUPPORTED BY A FLOOR OR BUMPER JACK.

INCLUDED HARDWARE:

Accessory Pack Contents:		
P/N	Qty.	Description
556R27	2	3" Torca Couplers
556R22	2	73.5mm Band Clamp
599R94	1	Blackheart Decal
505R44	4	1/4"-20 x .75" Flange Bolt
539R18	4	1/4"-20 Flange Nut

Parts List:		
Qty.	Description	
1	X-Pipe Assembly	
1	Driver's Link Pipe	
1	Passenger's Link Pipe	

INSTALLATION:

IMPORTANT: Inspect your accessory pack: BEFORE YOU START!

- 1. Place the vehicle on flat a surface, set the parking brake, and block the front wheels.
- 2. Disconnect the battery.
- 3. Lift the vehicle and support with jack stands.

WARNING! Never support a vehicle with a floor or bumper jack.

INSTALLATION OF THE BLACKHEART CAT-BACK EXHAUST:

- 1. Follow the instructions included with the 70103309-RHKR or 70103310-RHKR on how to install those long tube headers. These instructions assume these have already been installed.
- 2. Slide the 73.5mm band clamps onto the X-pipe section, sliding the two link pipes into the X-pipe. Loosely tighten the 73.5mm band clamps.
- 3. Lift the X-pipe into place. Using the OEM passenger's side hanger, hang the X-pipe assembly. The driver's side isolator will need to be removed.
- 4. Slide the 3" Torca couplers over the ends of the X-pipe link tubes. Slide the couplers over the collector of the headers, and loosely tighten the couplers.
- 5. Align the muffler assembly ball and sockets. Using the supplied hardware, attach the mufflers to the X-pipe.
- 6. Screw in the rear O2 sensor into the Hooker Blackheart X-pipe. Plug the rear O2 sensors into the vehicle harness.
- 7. Tighten all the hardware and clamps to lock the X-pipe in position. Starting at the header couplers, work your way to the muffler assembly connection.
- 8. Raise the car, remove the jack stands, and lower vehicle to the ground.
- 9. Start the vehicle and check for leaks and loose hardware.
- 10. Check all hardware again after the first 150 miles of driving.

Enjoy your Blackheart Exhaust!

- NOTE: It is normal for the Blackheart Exhaust to emit smoke for the first few minutes during break-in period.
- NOTE: By removing the catalytic converters the CEL will turn on. On 96-04 cars MIL Eliminators will turn the CEL off, or 98-04 cars a tune can turn the CEL off and get maximum power out of your new exhaust.

LIMITATION OF LIABILITY - DISCLAIMER:

The regulation of emissions production, noise levels, and safety standards is undertaken by the federal government, each of the fifty state legislatures, and by many local municipalities, towns, and counties.

HOOKER[™] makes no warranties of merchantability, of fitness for particular purpose, or that its products are approved for general use, or that its products comply with laws, regulations, or ordinances in the state where they may be sold to the ultimate purchaser, the consumer.

Unless expressly stated to the contrary in the catalog, instruction sheet; or price list, the entire risk as to the conformity of any company product in any such state and as to repair should the product prove to be defective or non-conforming, is on the retail purchaser, the buyer, the ultimate consumer, of such product and it is not upon the seller, distributor, or manufacturer.

In this connection, the retail purchaser, the buyer, the ultimate consumer assumes the burden of the entire cost of any and all necessary service, alterations, or repair.

THE FOREGOING STATEMENT LIMITS THE LIABILITY OF THE MANUFACTURER.

California vehicle code, sections 27156 and 38391, prohibits the advertising, offering for sale, or installation of any device, which modifies a vehicle's emission control system, unless exempted, unless otherwise noted. HOOKER[™] Headers that have not received an Executive Order (E.O.) exemption from these code sections are not legal for sale or use in California on vehicles originally equipped with catalytic converters, except for racing vehicles, which may never be driven upon a highway. Check with your local authorities to determine if these headers are legal for use in your particular area.

Technical Support: 1-866-464-6553

© 2015 Hooker Headers, Inc. All rights reserved.

199R11150 Date: 10-6-16