



199R11399

INSTALLATION INSTRUCTIONS

SniperEFI 1" Drop Base for 14" Diameter Air Cleaners P/N 120-510 & 120-511

- 1.) Remove any stock or existing air cleaner components. It is recommended to plug the throttle body bores to ensure that nothing falls into them during installation.
- 2.) Place the air cleaner gasket supplied with your *SniperEFI* unit (Holley P/N 108-4) onto the mounting flange.
- 3.) Align the raised bulges in the baseplate directly over any front mounted fuel fittings (Holley *Vapor Guard* P/N 759166ERL) on your *SniperEFI* throttle body and ensure that the baseplate is resting firmly on the air cleaner gasket with no obstructions. **WARNING! Inadequate clearance between the throttle lever and air cleaner base could result in an uncontrolled engine speed.**

Recommended Parts:

Holley Vapor Guard P/N 759166ERL, -6 90° to 3/8" Hose End

- 4.) Install the air cleaner mounting stud into the threaded hole on top of your *SniperEFI* throttle body, followed by your 14" diameter air cleaner element and lid. Be sure to remove any throttle body bore plugs you inserted in Step 1 before mounting the lid.
 - 5.) Remove any excess on your mounting stud (if necessary) and securely tighten your fastener of choice. **Always check for proper hood clearance before closing the hood.**
-



199R11399

INSTALLATION INSTRUCTIONS

SniperEFI 1" Drop Base for 14" Diameter Air Cleaners P/N 120-510 & 120-511

- 1.) Remove any stock or existing air cleaner components. It is recommended to plug the throttle body bores to ensure that nothing falls into them during installation.
- 2.) Place the air cleaner gasket supplied with your *SniperEFI* unit (Holley P/N 108-4) onto the mounting flange.
- 3.) Align the raised bulges in the baseplate directly over any front mounted fuel fittings (Holley *Vapor Guard* P/N 759166ERL) on your *SniperEFI* throttle body and ensure that the baseplate is resting firmly on the air cleaner gasket with no obstructions. **WARNING! Inadequate clearance between the throttle lever and air cleaner base could result in an uncontrolled engine speed.**

Recommended Parts:

Holley Vapor Guard P/N 759166ERL, -6 90° to 3/8" Hose End

- 4.) Install the air cleaner mounting stud into the threaded hole on top of your *SniperEFI* throttle body, followed by your 14" diameter air cleaner element and lid. Be sure to remove any throttle body bore plugs you inserted in Step 1 before mounting the lid.
- 5.) Remove any excess on your mounting stud (if necessary) and securely tighten your fastener of choice. **Always check for proper hood clearance before closing the hood.**