



**COMPETITION WHEEL STUDS
#4310G & 4311**

1. Remove hub or axle in which studs are to be replaced.
2. Knock out old studs using a hammer.
3. We recommend inserting the new studs using an arbor press. An alternate method would be to pull the studs in using the correct size nut, not a lug nut. It may be necessary to tap the head of the studs with a brass hammer or mallet as you are pulling them in with the nut.

CAUTION: UNDER NO CIRCUMSTANCES SHOULD THE NEW STUDS BE BEAT WITH A HAMMER!

NOTE: To install #4311 1/2" studs in Ford products and some other 1/2" stud applications, it will be necessary to enlarge stud holes to 21/32".

**199R12090
Date: 5-15-20**



**COMPETITION WHEEL STUDS
#4310G & 4311**

1. Remove hub or axle in which studs are to be replaced.
2. Knock out old studs using a hammer.
3. We recommend inserting the new studs using an arbor press. An alternate method would be to pull the studs in using the correct size nut, not a lug nut. It may be necessary to tap the head of the studs with a brass hammer or mallet as you are pulling them in with the nut.

CAUTION: UNDER NO CIRCUMSTANCES SHOULD THE NEW STUDS BE BEAT WITH A HAMMER!

NOTE: To install #4311 1/2" studs in Ford products and some other 1/2" stud applications, it will be necessary to enlarge stud holes to 21/32".

**199R12090
Date: 5-15-20**



**COMPETITION WHEEL STUDS
#4310G & 4311**

1. Remove hub or axle in which studs are to be replaced.
2. Knock out old studs using a hammer.
3. We recommend inserting the new studs using an arbor press. An alternate method would be to pull the studs in using the correct size nut, not a lug nut. It may be necessary to tap the head of the studs with a brass hammer or mallet as you are pulling them in with the nut.

CAUTION: UNDER NO CIRCUMSTANCES SHOULD THE NEW STUDS BE BEAT WITH A HAMMER!

NOTE: To install #4311 1/2" studs in Ford products and some other 1/2" stud applications, it will be necessary to enlarge stud holes to 21/32".

**199R12090
Date: 5-15-20**



**COMPETITION WHEEL STUDS
#4310G & 4311**

1. Remove hub or axle in which studs are to be replaced.
2. Knock out old studs using a hammer.
3. We recommend inserting the new studs using an arbor press. An alternate method would be to pull the studs in using the correct size nut, not a lug nut. It may be necessary to tap the head of the studs with a brass hammer or mallet as you are pulling them in with the nut.

CAUTION: UNDER NO CIRCUMSTANCES SHOULD THE NEW STUDS BE BEAT WITH A HAMMER!

NOTE: To install #4311 1/2" studs in Ford products and some other 1/2" stud applications, it will be necessary to enlarge stud holes to 21/32".

**199R12090
Date: 5-15-20**