

**1972-1993 Dodge Truck (D100/D150), 1987-1996 Dodge Dakota, & 1997-2004 Dodge Dakota  
8HP70 (Car), 8HP70 (2WD Truck), 8HP90 (Car)  
Transmission Adapter WB130045  
Installation Instructions**



Thank you for choosing to use White Box™ swap products as part of your GEN3 HEMI Swap project. This Trans adapter is part of the most comprehensively engineered system of mounting components, headers and exhaust systems available for this application. Please read these instructions thoroughly before attempting installation.

**PRE-INSTALLATION CONSIDERATIONS:**

- Requires the use of a rubber mount – Hooker 71223029HKR (black) 71223030HKR (red) or equivalent required
- Designed to be used with WB130011, WB130029, or WB130031 swap crossmember.

More GEN3 HEMI engine performance components, such as EFI fuel control systems, fuel filters, fuel pumps, plumbing hose/fittings, intakes, and valve covers can be found at [www.holley.com](http://www.holley.com).

**BEFORE BEGINNING:**

Check that the hardware package includes the following:

| Qty. | Description      |
|------|------------------|
| 6    | M10 x 25mm Bolts |
| 2    | M10 Flange Nuts  |

If you are missing any hardware, please contact Technical Service at 1-866-464-6553 or 270-781-9741.

**INSTALLATION:**

1. Using an 8HP transmission, install the adapter bracket to the rear of the transmission using the supplied hardware and tighten.
2. Install rubber transmission mount using the supplied hardware.
3. Raise the transmission high and install your crossmember and tighten.
4. Your trans adapter install has now been completed and ready to be outfitted with Hooker Blackheart Dodge truck swap headers and single/dual exhaust systems that are specifically designed for use with this crossmember.

**199R12247**  
**Date: 4-22-21**