



DINAN

D100-0942 SPRING SET; G01 X3 M40i

INSTALLATION NOTES

PLEASE READ BEFORE BEGINNING INSTALLATION

Please refer to the part number printed on each spring to determine the correct installation location:

- D100-1005 = Front Spring
- D100-1007 = Rear Spring

For best results, we recommend installation of the companion handling kit, p/n D193-0121.

Alignment:

- An alignment is required after installation.
- All Dinan suspension alignments are done with full fuel tanks and no weight inside the vehicle.
- Specifications are as follows:

FRONT:	Setting	Tolerance
Camber	-0.9°	± 0.42°
Caster	6.0°	± 0.5°
Total Toe	0.17°	± 0.07°
REAR:		
Camber	-1.5°	± 0.08°
Total Toe	0.27°	± 0.07°

If you encounter any difficulties during the installation, or if these instructions are not clear to you, please call Dinan's Technical Support Staff @ (800) 341-5480.

Happy Motoring!