

2005-09 MUSTANG **SIDE SCOOP INSERTS**

INSTALLATION INSTRUCTIONS FOR PART # **5R3Z-65290A76/7**

TOOLS NEEDED FOR INSTALLATION

- Drill with 5/16" drill bit
- Safety glasses
- Allen wrench
- Gloves

- WARNING! -

Always wear gloves and protective eye-wear when working around automotive equipment

- WARNING! -

Please review these instructions carefully. If any part of this procedure seems out of your scope of capabilities, please seek a certified mechanic to perform this installation.

INSTALLATION

1. Lay billet side scoop insert into scoop on car. Position appropriately. **Figure 1**
2. Mark holes to be drilled. **Figure 2**
3. Using 5/16" bit, drill two hole locations. **Figure 3**
4. Insert rubber nut pieces into holes.
5. Position billet side scoop into place again and bolt into place.
 - a. Start both bolts and then press insert firmly into scoop while tightening bolts. **Figure 4**



Figure 1



Figure 2



Figure 3



Figure 4