

	1	Step Spacer
	1	Socket Head Cap Bolt, M10 x 1.5 x 30
	2	Socket Head Cap Bolt, M10 x 1.5 x 80
	3	Socket Head Cap Bolt, M8 x 1.25 x 100
	2	Flange Head Bolt, M8 x 1.25 x 20
	2	Flange Head Bolt, M8 x 1.25 x 80
	2	Flange Head Bolt, M8 x 1.25 x 30
	1	Flange Head Bolt, M10 x 1.5 x 35
	1	Flange Head Bolt, M10 x 1.5 x 35
	1	Flange Head Bolt, M10 x 1.5 x 45

20-131 & 20-136 = 97-170