



INSTALLATION INSTRUCTIONS CHROME-PLATED VALVE COVER CAPS - 9847

FITS: SB CHEVY 1987-LATER INNER RAIL DESIGN FACTORY OEM VALVE COVERS

NOTE: The factory OEM valve covers do not have to be removed from the cylinder heads to install Mr. Gasket Valve Cover Caps. These valve cover caps fit over the factory valve covers and fasten to the cylinder head using existing mounting hardware or Mr. Gasket #9822 chrome-plated Hold-Down Kit. On some vehicle applications, it may be necessary to move or disconnect various auxiliary engine components to provide clearance for installing valve cover caps. If necessary, refer to the manufacturer's service manual for correct procedure.

CAUTION:

MAKE SURE ENGINE, RADIATOR, AND ALL AUXILIARY COMPONENTS ARE COOL BEFORE STARTING INSTALLATION.

1. The factory valve covers should be clean and free from dirt and oil.
2. Remove PCV valve(s) and oil filler cap from valve covers.
3. Remove hold-down bolts from center of valve covers. Hold-down bolts are equipped with torx-type head. For removal, use a no. 30 torx drive tip tool.

NOTE: If gaskets underneath factory valve covers are leaking and need to be replaced, use Mr. Gasket #168 or #5867 Ultra-Seal™ Valve Cover Gaskets for optimum sealing.

4. Place a bead of silicone sealer (use Mr. Gasket #78080G for optimum sealing) around the top of each mounting hole on the factory valve covers to prevent oil leakage.
5. Place valve cover cap over factory valve cover and push down until fully seated. Two (2) hole design fits driver's side and one (1) hole design fits passenger side cylinder head.
6. Insert hold-down bolts into mounting holes. Starting with the two (2) center bolts, tighten to manufacturer's specification.

NOTE: Use optional Mr. Gasket chrome-plated Hold-Down Kit #9822 to replace the existing factory mounting hardware. This kit consists of four (4) hold-down bolts, complete with four (4) flat washers for each valve cover.

7. Re-install the PCV valve(s) and oil filler cap into valve covers.

Contents made in Taiwan R.O.C./Printed in U.S.A.

The Mr. Gasket Performance Group • 1801 Russellville Road, Bowling Green, KY 42101 -

270-781-9741 - www.holley.com

Form No. 97140063



INSTALLATION INSTRUCTIONS CHROME-PLATED VALVE COVER CAPS - 9847

FITS: SB CHEVY 1987-LATER INNER RAIL DESIGN FACTORY OEM VALVE COVERS

NOTE: The factory OEM valve covers do not have to be removed from the cylinder heads to install Mr. Gasket Valve Cover Caps. These valve cover caps fit over the factory valve covers and fasten to the cylinder head using existing mounting hardware or Mr. Gasket #9822 chrome-plated Hold-Down Kit. On some vehicle applications, it may be necessary to move or disconnect various auxiliary engine components to provide clearance for installing valve cover caps. If necessary, refer to the manufacturer's service manual for correct procedure.

CAUTION:

MAKE SURE ENGINE, RADIATOR, AND ALL AUXILIARY COMPONENTS ARE COOL BEFORE STARTING INSTALLATION.

1. The factory valve covers should be clean and free from dirt and oil.
2. Remove PCV valve(s) and oil filler cap from valve covers.
3. Remove hold-down bolts from center of valve covers. Hold-down bolts are equipped with torx-type head. For removal, use a no. 30 torx drive tip tool.

NOTE: If gaskets underneath factory valve covers are leaking and need to be replaced, use Mr. Gasket #168 or #5867 Ultra-Seal™ Valve Cover Gaskets for optimum sealing.

4. Place a bead of silicone sealer (use Mr. Gasket #78080G for optimum sealing) around the top of each mounting hole on the factory valve covers to prevent oil leakage.
5. Place valve cover cap over factory valve cover and push down until fully seated. Two (2) hole design fits driver's side and one (1) hole design fits passenger side cylinder head.
6. Insert hold-down bolts into mounting holes. Starting with the two (2) center bolts, tighten to manufacturer's specification.

NOTE: Use optional Mr. Gasket chrome-plated Hold-Down Kit #9822 to replace the existing factory mounting hardware. This kit consists of four (4) hold-down bolts, complete with four (4) flat washers for each valve cover.

7. Re-install the PCV valve(s) and oil filler cap into valve covers.

Contents made in Taiwan R.O.C./Printed in U.S.A.

The Mr. Gasket Performance Group • 1801 Russellville Road, Bowling Green, KY 42101 -

270-781-9741 - www.holley.com

Form No. 97140063