

QUICK COOL

Installation Instructions for 300-4013 Quick Cool Insulator Kit

NOTE: MAKE SURE THE MANIFOLD FLANGE AREA IS CLEAN AND FREE OF DEBRIS BEFORE STARTING INSTALLATION PROCEDURES.

Please follow the steps below for proper installation of the Quick Cool Insulator Kit.



STEP 1



STEP 2



STEP 3



STEP 4



STEP 5



STEP 6



STEP 7



STEP 8

If you have questions or any other issues, please call our Technical Service phone line at 270-793-0900.