LS SWAP SELECTION GUIDE

1973-87 GM C-10/20 2WD

Step 1 - Select Engine Mounts

(Required for designed clearances)



73-87 GM C-10 LS-Swap Engine Mounting Brackets

12621HKR

Step 2 - Select Transmission Crossmember (Required for designed clearances)



Transmission being Installed	Required Components	
T56/T56 Magnum	T56 Magnum <u>12646HKR</u> , <u>12645HKR</u>	
200-4R	<u>12646HKR</u>	
TH400	<u>12646HKR</u>	
TH350	<u>12646HKR</u> , <u>12645HKR</u>	
700R4	<u>12646HKR</u> , <u>12645HKR</u>	
4L60-4L75E*	<u>12646HKR</u>	
4L80E/4L85E*	/4L85E* <u>12646HKR</u>	

12645HKR adapter bracket is required for installation of a TH350, 700R4, T56 or T56 Magnum transmission

*May require tunnel modification for installation on 73-80 model year trucks

Step 3 - Select Headers or Manifolds






Full Length Headers	Full Length Headers	Cast Iron Exhaust Manifolds	
w/ 1 ¾" Primaries and 3" Collector	w/ 1 1/8" Primaries and 3" Collector	w/ 2 ¼" Outlet	
70101503HKR (Black Painted)	70101504HKR (Black Painted)	8501HKR (Raw)	
70101503-1HKR (Silver Ceramic)	70101504-1HKR (Silver Ceramic)	8501-1HKR (Silver Ceramic)	
70101503-3HKR (Black Ceramic)	70101504-3HKR (Black Ceramic)	8501-3HKR (Black Ceramic)	
70101303-RHKR (304 Stainless Steel)	70101304-RHKR (304 Stainless Steel)	8501-4HKR (Titanium Ceramic)	
		8501-5HKR (Cast Iron Gray Ceramic)	

Step 4 - Select Exhaust System

(Short bed chassis only)



2 ½" Exhaust System w/ Mufflers	3" Exhaust System w/ Mufflers
70501414-RHKR (409 Stainless Steel, Side Exit)*	70501415-RHKR (409 Stainless Steel, Side Exit)*
70501416-RHKR (409 Stainless Steel, Rear Exit)	70501417-RHKR (409 Stainless Steel, Rear Exit)
70501314-RHKR (304 Stainless Steel, Side Exit)*	70501315-RHKR (304 Stainless Steel, Side Exit)*
70501316-RHKR (304 Stainless Steel, Rear Exit)	70501317-RHKR (304 Stainless Steel, Rear Exit)

^{*}Does not fit 56" (26" x 30") heavy duty springs

Step 5 - Select Adapter Pipes

(To connect headers/manifolds to exhaust system)



	Exhaust System (from Step 4)		
Headers/Exhaust Manifolds (from Step 3)	2 ½"	3"	
Full Length Headers	<u>42107HKR</u>	No Adapter Necessary (Headers Bolt Up Directly)	
8501 Series Exhaust Manifolds	<u>70701403-RHKR</u>	No Adapter Available	

Optional Accessories - Steps 6 & 7





Retro-Fit Oil Pan	Retro-Fit Oil Pan w/ Additional Front Clearance*
<u>302-1</u>	<u>302-2</u>

Step 7 - Select Accessory Drive Kit*

(Includes A/C compressor, Alternator, P/S Pump, Tensioner, Pulleys, Brackets, Hardware, and Wiring Pigtails)



LS Accessory Drive Kit w/	LS Accessory Drive Kit w/	LS Accessory Drive Kit w/	Low Mount LS Accessory Drive
R4 A/C Compressor	SD508 A/C Compressor	SD7 A/C Compressor	Kit w/ SD7 A/C Compressor
<u>20-136</u>	<u>20-137</u>	<u>20-138</u>	<u>20-162</u>

*Compatibility of Holley accessory drive kits requires use of 12621HKR engine mounting brackets. All accessory drive kits listed above require 21-1, 21-2, 21-3, or 21-4 installation kit depending on crankshaft pulley belt alignment. For more information and additional accessory drive components, please click the following link:

https://www.holley.com/products/ls_power/accessory_drives/