

# Headlamp Harness w/ Hi-Beam/Low-Beam Relays Installation Instructions

**\*\*These instructions are for vehicles with the battery on the passenger side. Reverse instructions for vehicles with battery on drivers side.\*\***

1. Unplug the headlights from the old harness. Plug the new headlight harness to each headlight. The longest set of wires goes to the driver side.
2. Locate the female, 3 PIN plug with the red & green wires on your new harness. Plug this into your passenger side original headlight male plug.
3. Connect the large red cable to battery power. (+ Positive) Connect the heavy duty black cable to body ground (- Ground)
4. Route the harness neatly away from the cooling fan and any sharp objects. Mount the relays and wrap any loose wires with electrical tape.
5. You can remove the old headlight connector, or tie it out of the way.

	Low Beam	High Beam
Autoworks Harness	Red	Green
O.E.M Ford Harness	Red/black	Green/blk
Centech Body Harness*	White	White
Painless Harness*	Red Or Tan	Red Or Tan

\*Wire Colors listed (Left) are not 100% accurate. Aftermarket body harnesses may change color coordination without notice