



## NEGATIVE CAMBER CONTROL ARMS INSTALLATION INSTRUCTIONS

PART NUMBER DI60-0006

|              |         |   |
|--------------|---------|---|
| APPLICATION: | 2011-12 | 528i/iX, 535i/iX, 550i/iX (F10)           |
|              | 2010-12 | 535i/iX GT, 550i/iX GT (F07)              |
|              | 2011-12 | 640i/iX, 650i/iX (F12, F13)               |
|              | 2013    | 640i GC, 650i/iX GC (F06)                 |
|              | 2009-12 | 740i/Li, 750i/Li/iX/LiX, 760Li (F01, F02) |
|              | 2011-12 | Alpina B7, B7X, B7L, B7LX (F01, F02)      |

Congratulations on being selective enough to use a Dinan Engineering Negative Camber Control Arms. We have spent many hours developing this kit to assure that you will receive maximum performance and durability with minimum difficulty in installation. Please take the time to read these instructions and call us if you have any difficulties during the installation.

**DO NOT WORK ON VEHICLES SUPPORTED BY A JACK ONLY. USE SECURE JACK STANDS!**

---

### PARTS LIST

| Qty | Part #    | Description               |
|-----|-----------|---------------------------|
| 2   | DI63-0010 | Upper Negative Camber Arm |

---

### INSTALLATION NOTES:

- Install control arms per BMW recommended procedure.
- Some hardware may need to be replaced. Please review the procedure and have these pieces on hand as needed.
- These arms alter the camber in the front suspension by  $-0.5^{\circ}$ . An alignment will be required after installation of these control arms.