

Detroit Speed Billet Hood Latch Pin 1964-1967 A-Body, 1970-1972 A-Body, 1962-1974 Chevy II/Nova, & 1967-80 C10 Truck P/N: 011702DS & 011703DS

Thank you for the purchase of the Billet Hood Latch Pin from Detroit Speed. The hood latch pin is machined from 304 series stainless steel and will help dress up a usually forgotten area.



P/N: 011702DS

P/N: 011703DS

ltem	Description	Quantity
1	Stainless Steel Hood Latch Pin	1
2	1/2"-20 Stainless Steel Jam Nut	1
З	1/2" AN Stainless Steel Washer	1
4	Instructions	1

Instructions:

- 1. To begin installation, adjust the hood to the best possible position on the car. Be sure to check the gaps as well as the closed height for the front and rear.
- 2. After checking hood alignment, measure the distance from the end of the hood latch pin to the base of the hood latch plate. Record this distance.
- 3. Loosen the jam nut and thread the hood latch pin from the hood latch plate.
- 4. Reassembly can now begin. Apply a small amount of anti-seize to the threads of the hood latch pin. Thread the jam nut onto the hood latch pin followed by the washer. Now thread the hood latch pin into the hood latch plate on the hood. Thread the pin to the distance recorded in Step 2. Once adjusted to the correct length, tighten the jam nut.

- 5. Close the hood and check for hood fitment. Adjust the striker as necessary to obtain proper closure depth. If adjustment is necessary, loosen the jam nut and thread the pin in the appropriate direction. A #1 Phillips screwdriver can be inserted into the hole in the side of the hood latch pin to make this easier.
- 6. Once the final adjustments have been made, the installation of the hood latch pin is now complete.

If you have any questions before or during the installation of this product, please contact Detroit Speed at <u>tech@detroitspeed.com</u> or 704.662.3272