

# INSTALLATION INSTRUCTIONS

1. Disconnect battery
2. Remove factory part
3. Install Holley component
4. Tighten fasteners
5. Connect wiring / fuel
6. Reconnect battery
7. Turn key
8. Enjoy improved performance