



LAKEWOOD REAR ANTI-ROLL BAR CENTER LINKS REMOVAL AND INSTALLATION INSTRUCTIONS 2005 – 2011 MUSTANG PART NO. 19101

Thank you for your purchase from Lakewood Industries. For technical assistance, please call 216-688-8300 Monday thru Friday 8:30 AM to 5:00 PM EST.

WARNING: DUE TO THE TECHNICAL NATURE OF THIS PRODUCT, AND SPECIALIZED EQUIPMENT, PROFESSIONAL INSTALLATION IS RECOMMENDED.

CAUTION: INSTALLATION OF THIS PRODUCT REQUIRES WORKING UNDER THE VEHICLE. IT IS THE RESPONSIBILITY OF THE INSTALLER TO ENSURE A SAFE WORKING ENVIRONMENT. THE USE OF AN AUTOMOTIVE LIFT IS RECOMMENDED. MAKE SURE THAT THE VEHICLE IS SAFELY SUPPORTED AND ALWAYS USE JACK STANDS. ALWAYS WEAR SAFETY GLASSES.

Section 1 – Disassembly

1. Properly raise and support the vehicle either on an automotive lift or ramps.

Note: The use of jack stands to perform this installation is not recommended.

2. Remove the fasteners from the anti-roll bar end bushings, located on the bottom of the shock mounts of the rear axel housing.
3. Remove the fasteners which connect the anti-roll bar center links to the body.
4. Remove the anti-roll bar from the vehicle and slide the end bushings and center links off of the bar.

Tip: The use of a spray type lubricant may ease the removal and installation of the bushings and links.

Section 2 - Installation

1. Install the center link and the end bushings onto the bar.
Note: Use O.E. P#7R32Z-5493-A for a heavy duty 24mm bar or P#AR3Z-5493-A for standard duty 17mm bar.

2. Install the Lakewood heavy duty center link into the mounting point of the body using the fastener previously removed in step 2 of section I. Do not fully tighten at this time.

3. Reinstall the anti-roll bar into the vehicle by attaching the end bushings to the mounting points on the rear axel housing. Do not fully tighten at this time.

4. Align the center link insulators with the center links, and install into H.D link with the covers and fasteners provided in the installation kit.

5. Tighten all fasteners to complete the installation.

Go to: www.prestoliteperformance.com
to see a video installation of this product.

LAKEWOOD CHASSIS AND SUSPENSION PRODUCTS ARE ENGINEERED AND MANUFACTURED TO IMPROVE THE PERFORMANCE OF YOUR VEHICLE. WE ENCOURAGE YOU TO ENJOY USING OUR PRODUCTS SAFELY AT A SANCTIONED RACING FACILITY. PLEASE OBEY ALL TRAFFIC LAWS.



LAKEWOOD IS A TRADEMARK OF PRESTOLITE PERFORMANCE
10601 MEMPHIS AVE #12, CLEVELAND, OH 44144
216.688.8300 FAX 216.688.8306

FORM 97146778
08/10
Made in U.S.A.
Printed in U.S.A.