



**INSTALLATION INSTRUCTIONS
CARBURETOR VIBRATION ISOLATOR
#4277G & #4278G**

This carburetor isolator absorbs engine vibration and reduces fuel foaming, erratic needle/seat motion and stabilizes fuel curve.

Install carburetor isolator between carburetor and intake manifold. This replaces the normal carburetor gasket. No gasket sealer is required to seal isolator. Torque carburetor hex nut FASTENERS to 60-80 inch lbs.

97144280
Date: 4-19-18



**INSTALLATION INSTRUCTIONS
CARBURETOR VIBRATION ISOLATOR
#4277G & #4278G**

This carburetor isolator absorbs engine vibration and reduces fuel foaming, erratic needle/seat motion and stabilizes fuel curve.

Install carburetor isolator between carburetor and intake manifold. This replaces the normal carburetor gasket. No gasket sealer is required to seal isolator. Torque carburetor hex nut FASTENERS to 60-80 inch lbs.

97144280
Date: 4-19-18



**INSTALLATION INSTRUCTIONS
CARBURETOR VIBRATION ISOLATOR
#4277G & #4278G**

This carburetor isolator absorbs engine vibration and reduces fuel foaming, erratic needle/seat motion and stabilizes fuel curve.

Install carburetor isolator between carburetor and intake manifold. This replaces the normal carburetor gasket. No gasket sealer is required to seal isolator. Torque carburetor hex nut FASTENERS to 60-80 inch lbs.

97144280
Date: 4-19-18



**INSTALLATION INSTRUCTIONS
CARBURETOR VIBRATION ISOLATOR
#4277G & #4278G**

This carburetor isolator absorbs engine vibration and reduces fuel foaming, erratic needle/seat motion and stabilizes fuel curve.

Install carburetor isolator between carburetor and intake manifold. This replaces the normal carburetor gasket. No gasket sealer is required to seal isolator. Torque carburetor hex nut FASTENERS to 60-80 inch lbs.

97144280
Date: 4-19-18



**INSTALLATION INSTRUCTIONS
CARBURETOR VIBRATION ISOLATOR
#4277G & #4278G**

This carburetor isolator absorbs engine vibration and reduces fuel foaming, erratic needle/seat motion and stabilizes fuel curve.

Install carburetor isolator between carburetor and intake manifold. This replaces the normal carburetor gasket. No gasket sealer is required to seal isolator. Torque carburetor hex nut FASTENERS to 60-80 inch lbs.

97144280
Date: 4-19-18



**INSTALLATION INSTRUCTIONS
CARBURETOR VIBRATION ISOLATOR
#4277G & #4278G**

This carburetor isolator absorbs engine vibration and reduces fuel foaming, erratic needle/seat motion and stabilizes fuel curve.

Install carburetor isolator between carburetor and intake manifold. This replaces the normal carburetor gasket. No gasket sealer is required to seal isolator. Torque carburetor hex nut FASTENERS to 60-80 inch lbs.

97144280
Date: 4-19-18