

## Digital Dash Firmware 6.0 Build 258

This update contains the unified firmware on Rev E and newer units. This update cannot be used for earlier hardware versions.


This update will work with the following ECUs:

- Holley EFI HP and Dominator V4, V5 and V6
- Holley Terminator X and Terminator X Max (V1, V2, V3)
- Holley Sniper
- Stand-alone applications.

## Firmware Update Procedure

### Preparation

You will need to extract the files onto the root folder of a FAT (not exFat) formatted USB memory stick. See image below, the .bin files can NOT be stored under any directory. They must be placed in the root of the “USB DRIVE”. Please ensure that you have only one .bin file on the memory stick.



### Installation Instructions

Once the update process starts, it is important to not remove power until after the update process is complete. The total process will take approximately 2 minutes.

1. Open the .zip file and copy the individual .bin file to the root folder of a USB memory stick. Ensure you eject/safely remove the USB memory stick from your computer.
2. Insert the USB memory stick into one of the USB ports on the dash
3. Power on your dash, go to the main menu, press *Configuration*, then press *Update Firmware*.
4. You may have to press OK to continue, allow the process to compete and it will power cycle the dash by itself. When it boots back up it may reprogram the coprocessor – it is important to let this complete.  
**NOTE:** If you see the “Updating Firmware” message for more than 2 full minutes, you may power off and try again.
5. When the dash comes back online, verify the firmware update was successful. Go to the main menu, press *Configuration* and then press *About*. The top line should read: “DigDash SW version 6.0 build 258 HW rev E”.

6. Turn off the dash and remove the USB stick.

**Note to installers:**

Some units may require a second run of the updater. Press the 'About' button from the configuration menu of the dash after it powers back up to verify the firmware update has been applied, it should read "DigDash SW version 6.0 build 258 HW rev xx".

If it does not, with your USB stick still plugged in, go back to the main menu, choose the 'Configuration' button, and select 'Update Firmware'.

After the update file is accepted, the unit will reboot automatically. If it does not reboot by itself, then wait two minutes and cycle the power.

**Firmware Release Notes****V6.0.258**

- Initial release for Rev E boards