



## TRI-BAR SPINNER INSTALLATION

1. Install your Halibrand wheels onto the vehicle and torque the lug nuts to the appropriate spec for your application.

**NOTE! The Halibrand tri-bar spinner, lug cover, spinner adapter, and corresponding spinner adapter mounting hardware are stylistic components which are not required to safely use your vehicle with properly installed Halibrand wheels.**

2. Align the spinner adapter mounting holes with the pre-drilled and tapped holes in your Halibrand wheel. Use the included split lock washers and hex head bolts to securely fasten the spinner adapter to the wheel and torque each bolt in a crisscrossed pattern to 35 ft-lbs.
3. Place the lug cover over the threaded end of the spinner adapter and use the alignment pin on the underside to properly place and seat the cover into the mounting flange on the wheel.
4. With the lug cover in place and aligned with only a small, even gap visible from the side, install the tri-bar spinner by screwing it onto the threaded adapter in a clockwise direction.

**IMPORTANT! The tri-bar spinner should only be installed hand-tight and then secured with a few small blows on the center of the tri-bar wings from a non-marring hammer.**

Once fully tightened down to a snug fit, the spinner should make a good seal with the lug cover and it will gently tighten the entire assembly against the flange on the wheel.

5. Using snap ring pliers, install the included snap ring onto the groove in the spinner adapter. Be careful not to scratch the outside surface of the spinner with the tips of your snap ring pliers. Make sure the snap ring is fully seated into the groove before proceeding.
6. Repeat steps 2-5 on your remaining Halibrand wheels and enjoy the ride.

