

PROConnect™

INSTALLATION INSTRUCTIONS

Congratulations, you have just purchased the highest quality ignition wire set available in the aftermarket today. To ensure you install your new spark plug wires correctly, use the following installation instructions and tips.

1. Make sure the engine has cooled down before attempting to remove any of the spark plug wires.
2. To ensure correct engine firing order, remove and replace only one spark plug wire at a time, starting with the longest wire first.
3. Remove any clips and wire separators and then grasp the spark plug end terminal and boot. Remove with a steady rotating pull. **NOTE: Avoid the use of pliers, screwdrivers, or other tools to remove the spark plug boot.** Clean off any excess grease found on the spark plug end or coil tower with a soft cloth and isopropyl alcohol.
4. Open the small packet of dielectric grease supplied with this set of wires and apply a very small amount to the inside3 of the spark plug boot to aid both installation and future removal.
5. Attach new wire to spark plug. Reattach clips and route new wire back through the separators again to the distributor cap or ignition coil. This will ensure that you have followed the original wire routing which is designed to keep the wire away from all linkages, the exhaust manifold, other hot surfaces, and any sharp edges.
6. Place the distributor end terminal and nipple over the distributor cap or ignition coil and firmly attach new wire.

INSTALLATION TIP: When you attach the wire end onto the spark plug, distributor cap, or coil, listen and feel for a click. This click indicates that the snap lock terminal has fully engaged.

NOTE: On any vehicles equipped with a separate coil wire, repeat steps 1-5.

860491

Date: 1-13-17

PROConnect™

INSTALLATION INSTRUCTIONS

Congratulations, you have just purchased the highest quality ignition wire set available in the aftermarket today. To ensure you install your new spark plug wires correctly, use the following installation instructions and tips.

1. Make sure the engine has cooled down before attempting to remove any of the spark plug wires.
2. To ensure correct engine firing order, remove and replace only one spark plug wire at a time, starting with the longest wire first.
3. Remove any clips and wire separators and then grasp the spark plug end terminal and boot. Remove with a steady rotating pull. **NOTE: Avoid the use of pliers, screwdrivers, or other tools to remove the spark plug boot.** Clean off any excess grease found on the spark plug end or coil tower with a soft cloth and isopropyl alcohol.
4. Open the small packet of dielectric grease supplied with this set of wires and apply a very small amount to the inside3 of the spark plug boot to aid both installation and future removal.
5. Attach new wire to spark plug. Reattach clips and route new wire back through the separators again to the distributor cap or ignition coil. This will ensure that you have followed the original wire routing which is designed to keep the wire away from all linkages, the exhaust manifold, other hot surfaces, and any sharp edges.
6. Place the distributor end terminal and nipple over the distributor cap or ignition coil and firmly attach new wire.

INSTALLATION TIP: When you attach the wire end onto the spark plug, distributor cap, or coil, listen and feel for a click. This click indicates that the snap lock terminal has fully engaged.

NOTE: On any vehicles equipped with a separate coil wire, repeat steps 1-5.

860491

Date: 1-13-17

LIMITED LIFETIME WARRANTY

PROConnect Inc., as manufacturer, warrants solely to the original purchaser and only as installed on the engine/application on which it was originally installed that this custom spark plug wire set is free from defects in material and/or workmanship and under normal operation conditions will not fail over the entire life of the engine. PROConnect does not warrant this product when transferred to another engine or when installed on engines/applications used for commercial purposes.

Under this warranty, Manufacturer's obligation is limited to the defective spark plug wire set. Cost of removal and installation is not included. If failure should occur, return defective spark plug wire set with invoice or sales receipt for verification and replacement under this warranty to (1) the selling distributor, or (2) another authorized distributor in your state.

PROConnect Inc. is not responsible for injury, property damage or other consequential damages arising directly or indirectly out of the use of this product, notwithstanding the fact that said injury, property damage or other consequential damages arose directly or indirectly from an actual alleged defect in material and/or workmanship.

The period of all implied warranties applicable to the spark plug wire set, including any implied warranty of merchantability or fitness for a particular purpose, is limited to the entire life of the engine on which it was originally installed for so long as the engine is owned by the original purchaser of the spark plug wire set.

LIMITED LIFETIME WARRANTY

PROConnect Inc., as manufacturer, warrants solely to the original purchaser and only as installed on the engine/application on which it was originally installed that this custom spark plug wire set is free from defects in material and/or workmanship and under normal operation conditions will not fail over the entire life of the engine. PROConnect does not warrant this product when transferred to another engine or when installed on engines/applications used for commercial purposes.

Under this warranty, Manufacturer's obligation is limited to the defective spark plug wire set. Cost of removal and installation is not included. If failure should occur, return defective spark plug wire set with invoice or sales receipt for verification and replacement under this warranty to (1) the selling distributor, or (2) another authorized distributor in your state.

PROConnect Inc. is not responsible for injury, property damage or other consequential damages arising directly or indirectly out of the use of this product, notwithstanding the fact that said injury, property damage or other consequential damages arose directly or indirectly from an actual alleged defect in material and/or workmanship.

The period of all implied warranties applicable to the spark plug wire set, including any implied warranty of merchantability or fitness for a particular purpose, is limited to the entire life of the engine on which it was originally installed for so long as the engine is owned by the original purchaser of the spark plug wire set.