




30-803

INSTALLATION INSTRUCTIONS FOR 30-803 FUEL PRESSURE REGULATOR



Installation of this regulator should follow the above illustration to route the fuel lines. The ports are 3/8" pipe thread. Use the provided mounting bracket to mount the regulator.

This regulator has been preset at 6.5 P.S.I. with a certified calibrated gauge. If your gauge reads radically different from 6.5 P.S.I., then either your gauge is no longer reading correctly or there is a problem with the fuel system from operating properly.


If you are experiencing any difficulty in your installation or are having other issues please call our technical service phone line at 1-866-464-6553.

© 2010 QUICK FUEL TECHNOLOGY 99-30-803



30-803

INSTALLATION INSTRUCTIONS FOR 30-803 FUEL PRESSURE REGULATOR



Installation of this regulator should follow the above illustration to route the fuel lines. The ports are 3/8" pipe thread. Use the provided mounting bracket to mount the regulator.

This regulator has been preset at 6.5 P.S.I. with a certified calibrated gauge. If your gauge reads radically different from 6.5 P.S.I., then either your gauge is no longer reading correctly or there is a problem with the fuel system from operating properly.

If you are experiencing any difficulty in your installation or are having other issues please call our technical service phone line at 1-866-464-6553.

© 2010 QUICK FUEL TECHNOLOGY 99-30-803