

MSD INSTALLATION INSTRUCTIONS

HONDA/ACURA Blaster Coils Red, PN 8237, Single, PN 82376, 6 Pack Black, PN 82373, Single, PN 823763, 6 Pack

Read the instructions before attempting the installation.

Parts Included, Single Coil:
1 - Coil

Parts Included, 6 Pack Coils:
6 - Coils

WARNING: During installation, disconnect the battery cables. When disconnecting the battery, always remove the Negative cable first and install it last.




Figure 1 Coils

MOUNTING

The MSD Coil is designed to be a direct replacement, due to the number of applications available, the mounting of the coils may be slightly different.

1. Remove the coil covers (if supplied) from the valve covers.
2. Disconnect the factory connector, remove the coil retaining bolts and remove the coil.
3. Install the MSD Coil in the same position as the original coil.
4. Connect the wiring harness and the coil retaining bolts.

