Digital Dash v4.0 Build 29

This update is for Rev B, C and D Digital Dash with date code lower than *160201 xxx*:

This update file contains USB GPS and 553-107 Shift Light support. It contains V4.0.29 software for V4 EFI connected or standalone applications.

Extract the files onto the root folder of a USB memory stick. Once the update process starts, it is important to not remove power until after the update process is complete.

Installation Instructions

1. Extract the files to a USB memory stick. Ensure you eject/safely remove the USB memory stick from your computer.
2. Power off your dash
3. With the dash powered off, insert the USB memory stick into one of the USB ports on the dash
4. Power on the dash. After a short time you should see a message that it is updating the software. Wait until you see the gauge screen appear before continuing.
5. Turn off the dash and remove the USB stick.

Note to installers:

Click the 'About' button from the main menu of the dash after it powers back up to verify the firmware update has been applied, it should read "SW version 4.0 build 29" If it does not, with your USB stick still plugged in, go back to the main menu, choose the 'Configuration' button and select 'Update Firmware'.

After the update file is accepted, it will change the filename to installed_fw-dash-4.0.29b.tgz. If you need to update another unit, rename the file to remove the 'installed_' prefix. (i.e., rename the file back to fw-dash-4.0.29b.tgz)