


14. Apply a small amount of RTV sealant to the exposed threads of the load screws, then install the 2 supplied jam nuts on the load screws. Tighten the jam nuts to 5 ft-lbs torque.
15. Apply 2 wraps of nylon thread tape to the magnetic drain plug, install it in the differential cover, and tighten it to 25-30 ft-lbs torque.



16. Fill the differential with manufacturer-specified gear oil. The bottom of the fill hole is the proper level.
17. Apply 2 wraps of nylon thread tape to the fill plug, install it in the differential cover, and tighten it to 25-30 ft-lbs torque.
18. Reinstall and tighten any vehicle parts (e.g., sway bar, Panhard rod) that may have been removed.

Congratulations, the installation of your B&M differential cover is now complete!

IMPORTANT: RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.

